



RRConcepts.com

SHUTTLE v2

<http://manuals.RRConcepts.com>

Restart Learn: - Press button #1.

Program Mode: - Turn speed dial counter-clockwise.

Factory reset: - In Program Mode, press both buttons 1 & 3.

How to operate: - Self-Adjusting Automatic Mode -

- Power up or Press button #1 when running.
- Do not touch anything, expect long delays at first.
- Dial sets top speed of train.
- Learn restarts on power up unless RESUME is set.

How to operate: - Manual Mode -

- Press button #3 when deceleration should start.
- Repeat three times after reversing.
- Dial sets creeping speed of train into diodes.
- Button #3 can be pressed multiple times.

Operating Modes: (GREEN Program Mode)

- 1 blink = RESUME; Retain settings on power up.
- 2 blinks = Super Realistic "Slow Creep" mode.
- 3 blinks = Never Shut Down.
- 4 blinks = Double siding 3 train hookup.

Delays:

- 1: 0 sec.
- 2: 5 sec.
- 3: 10 sec.
- 4: 15 sec.
- 5: 20 sec.
- 6: 30 sec.
- 7: 1 min.
- 8: 2 min.
- 9: 5 min.
- 10: 10 min.
- 11: 30 min.
- 12: 60 min.
- 13: Infinite