







SHUTTLE V3

How to operate:

- Set the Transformer to the Running Speed of the Train.
- If Needed, Press the Button to Restart the Learn Operation.
- Sit Back and Watch.
- The Train may stop short but will eventually go to the diode after 30 seconds as it learns. Each run will get better.
- Learn remembers on every power up. Restart rarely needed.

How to Set the Pause Time:

- When the train is paused, turn the dial until the desired color appears:

Pause Time Colors				
				
5 Minutes	1 Minute	20 Seconds	10 seconds	5 Seconds